



**NOTES:**

1. NEW CRICKETS SHALL BE SEALED BY PLACING A BEAD OF TROPICAL #950/951 MASTIC FOR ACRYLIC OR, TROPICAL # 9100 MASTIC FOR SILICONE UNDER THE FLANGES BEFORE THEY ARE MECHANICALLY ATTACHED
2. VERTICAL SEAMS TO BE CUT BACK A MINIMUM OF 2" FROM CRICKET
3. RIMING - REFER TO TROPICAL ROOFING PRODUCTS SPECIFICATIONS FOR DECK PRIMING REQUIREMENTS.

NOTE: FOR SPECIFIC PRODUCT RECOMMENDATION REFER TO THE APPROPRIATE FLUID APPLIED SYSTEM GUIDE SPECIFICATIONS AT [WWW.TROPICALROOFINGPRODUCTS.COM](http://WWW.TROPICALROOFINGPRODUCTS.COM)



**FLUID APPLIED RESTORATION COATING SYSTEM**

**SKYLIGHT CURB DETAIL**

DATE :  
**12-13-16**

DETAIL NO :  
**28**