



SECTION

GUTTER PLAN

NOTES:

1. PREPARE ALL GUTTER SURFACES AS REQUIRED BY FLUID APPLIED SYSTEM MANUFACTURER.
2. PRIME ENTIRE GUTTER WITH #960 METAL PRIMER @ 200 SF/GAL MINIMUM COVERAGE.
3. REMOVE LOOSE OR DAMAGED FASTENERS AND REPLACE WITH FASTENERS DESIGNED TO PENETRATE THE DECK AND SUPPORTING MEMBERS WITH NEOPRENE WASHERS AT THE SCREW HEAD.
4. GUTTER CONFIGURATIONS MAY DIFFER FROM THE PROFILE INDICATED, BUT THE APPLICATION SHALL REMAIN SIMILAR.
5. FLUID APPLIED RESTORATION COATING SYSTEM - BASE COAT, REINFORCED FABRIC, BASE COAT 2, AND FINISH COAT COMPONENTS. ALL GUTTER SEAMS ARE TREATED WITH BASE COAT AND 4" OR 6" FABRIC DEPENDING ON GUTTER PROFILE. ALL FASTENERS ARE TREATED WITH #950/951 (ACRYLIC) OR #9100 (SILICONE).

NOTE: FOR SPECIFIC PRODUCT RECOMMENDATION REFER TO THE APPROPRIATE FLUID APPLIED SYSTEM GUIDE SPECIFICATIONS AT WWW.TROPICALROOFINGPRODUCTS.COM



FLUID APPLIED RESTORATION COATING SYSTEM

TYPICAL GUTTER DETAIL

DATE :
12-13-16

DETAIL NO :
8